

CARANK HANDLE CONTROL BUTTON: - 61,62

→ 230

238

TRACK SECTION	DP NUMBERS
TS 06	DP-27,28,29,30,31,32,38
TS 07	DP-33,34,35,36,37.

Figure 6

