




BARANAGAR STATION
UP LINE / DOWN LINE
TO DAKSHINESWAR
TO NOAPARA
CR1
AT PANEL ROOM
N
1 W 1/1
LEVER
DN 1T(Shed)CR
DN 2T(Shed)CR
DN 1T(Shed)CR
DN 1T(Shed)CR
DN 1