


RCD →



RESET PANEL
ACE-1 UP(KNOA)

SM KEY	TS1165
TS1011	TS1060
TS1086B	TS1018
TS1063	
TSC-1063	
TS1061	
TS1083B	
TS C1061	

RESET PANEL
ACE-2 DN (KNOA)

SM KEY	
TS1016	TS1068A
TS1064	TS1068
TS1086A	TS129
TS1010	TS121/122
TS1085	TS123
TS1083A	TS90A
TS 1084	TS89A
TS 1068B	TS88A

NOTE: 1) TS 1086B, TS1063, TS1061, TS1083B, TS1165, TS1064, TS1086A, TS1010, T1085, TS1083A, TS1084, TS1068B ARE COMMON UNDER ACE-1 & ACE-2.
 2) TS C1061, TSC1063 & TS1011 ARE EXCLUSIVELY UNDER ACE-1.
 3) TS 1016, TS1068A, TS1068, TS129, TS121/122, TS123, TS90A, TS89A, TS88A ARE EXCLUSIVELY UNDER ACE-2.

RCD →

ACE-2 DN (30DP, 21TS)

ACE-1 UP (22DP, 15TS)

ACE - AXLE COUNTER EVALUATOR
RCD - REFERENCE COUNT DIRECTION

NOAPARA SH. NO. 01/13